



BUBBLE MACHINE Z10/Z30



User's instruction manual

This manual contains important information about the safe installation and use of this product. Please read this instruction manual carefully before installing or operating. Please keep these instructions in a safe place for future reference.



Congratulations on the purchase of your Z10/Z30 bubble machine.

With its one liter tank capacity and built-in fan, The Light Emotion Z10 will pump out enough bubbles to make magic happen, impressing all - particularly the children. Perfect for all kinds of functions including birthday parties, play rooms, school plays and much more.

The Z30 is a monster bubble maker. Integrated high-power fans blow bubbles over 10 meters, making this unit especially suited for outdoor use* and highly recommended for installation or hire for that big event on your calendar. The extra-size 3L tank and the large output of the Z30 make it extremely suited to parades and festivals.

With the specially formulated fluid* which produces bubbles with a long hang-time - the room will be floating along on literally hundreds those little spheres of magic. It's an effect that never stops causing awe and delight. The bubble machines are supplied with a hanging bracket and remote control which will even let you control constant or timed bursts of bubbling fun.

*(Note: requires Bubble fluid to operate, available separately, Unit may be suitable for outdoor use but is not IP rated and cannot be left in the rain or be subjected to moisture.)

CONTENTS

SECTION	Page
WHAT IS INCLUDED	2
SAFETY INSTRUCTIONS, POWER	3
OPERATION INSTRUCTIONS	4
SPECIFICATIONS	5

Please note that as part of our ongoing commitment to continuous improvement and product development, the specifications in this manual are subject to change without notice. Whilst every care has been taken in the preparation of this manual we reserve the right to change specifications in the course of product improvement.

WHAT IS INCLUDED:

- 1x Bubble Machine
- 1x Power Cord
- 1x User Manual and Warranty Card
- 1x Remote control

SAFETY INSTRUCTIONS:

Please read these instructions carefully. It includes important information about the installation usage and maintenance of this product.

- Do not overfill your bubble machine. Overfilling will cause the unit to leak.
Danger of electric shock
- Switch off from mains when refilling the liquid or cleaning the system.
- Do not transport with liquid. If the machine get wet, do not use until it is completely dry.
- Keep this device dry.
- Keep the bubble machine upright.
- Turn off or unplug when not in use.
- This machine is not water-proof or splash-proof. If moisture, water, or any liquid gets inside the housing, immediately unplug the unit and contact your Light Emotion dealer before using it again.
- No user serviceable parts inside. Refer to your Light Emotion dealer.
- For indoor use only. Not designed for outdoor use.
- This appliance must be earthed.
- For adult use only. The bubble machine must be installed out of the reach of children. Never leave the unit running unattended.
- Never aim the output at open flames.
- Extended use will make all surfaces slippery.
- Position output of bubbles away from persons.
- Regular cleaning of the bubble wheel is required.
- Bubble liquid may leave permanent marks on clothing.
- Bubbles and fluid can leave a slippery surface.

POWER:

CAUTION: This light emotion is designed to operate on 240VAC

Power Consumption: max 40W

Fuse: M205 1A fast blow

OPERATION INSTRUCTIONS

SET UP

- Remove all packing materials from the bubble machine.
- Place bubble machine on flat surface.
- Loosen the side screws and lift the housing upwards. You will see a liquid tank.
- Pour bubble liquid into the liquid tank, being careful not to exceed the maximum fluid level as specified by the specifications. **DO NOT OVERFILL.**
- When the container is full, lower the housing and tighten the screws.

FILL THE LIQUID

1. Ensure your bubble machine is unplugged from the mains electrical supply before attempting to open the housing. We take Z10 as an example.

2. To help avoid accidental exposure to dangerous live AC mains voltage, two safety screws are fitted that require a screwdriver to remove. Once these are removed, the finger screws can be undone by hand.



3. Once the screws are removed, the lid of the housing can be carefully swung upwards, as shown above. Take care not to spill any of the bubble fluid inside the unit.



4. The fluid tank is designed to fit only one way around. Make sure you insert it correctly, as shown above, with the lower edge facing into the machine.



OPERATION:

Connect power cable to the unit.

Press the [POWER] button on the controller, both the Red LED and Green LED will illuminate, indicating that is ready for use.

		LED	Function
Hold [ON/OFF] Button		The Greed LED on the top of ON/OFF button is turn off.	You will notice that the internal bubble drum and fan are activated. Bubbles are produced.
Push [TIMER] Button	Switch [DURATION] Pot	The Amber LED on the top of TIMER button is turn on.	Adjust the duration of bubble drum operate every time. (short to long)
	Switch [INTERVAL] Pot		Adjust the interval of bubble drum operate. (short to long)

SPECIFICATIONS:

	Z10	Z30
Weight	4.5Kg	8.5Kg
Size	L370 x W200 x H200mm	L370 x W280 x H200mm
Power input	240VAC 50Hz	240VAC 50Hz
Max Power consumption	40W	40W
Fuse	Fast blow 1A M205	Fast blow 1A M205
Input connection	Power - Male IEC	Power - Male IEC
Colour	Silver and black	Silver and black
Tank Capacity	1L	3L
Fluid Consumption	600mL/hr	1.2L/hr
Hanging Bracket	Yes	Yes
Lead	Fixed remote 2m	Fixed remote 2m
Construction	Metal casing	Metal casing